

Orion AW


The Orion AW is our deluxe convertible belt pack/backpack, a favourite of active outdoor photographers. It comes complete with a lowepro dayPack for storing clothing, food and other equipment you might need for a day in the field. 35mm capacity: 1 SLR, 3-5 lenses, flash and accessories



- Daypack clips into the belt pack and provides support for the load
- All Weather Cover protects the pack and your gear from hot sun, dust, sand rain, or snow
- Reverse Open Lid for fast, convenient access to equipment
- Built-in Waistbelt easily adjusted to fit your waist
- Mesh Lumbar Pad prevents back fatigue on long hikes and the breathable mesh wicks away moisture
- Overlap Zipper gives better protection and is easier to open than a standard zipper
- BatWing straps compress and secure the load to your body
- Laminated Mesh pocket protects delicate accessories and camera surfaces
- Adjustable Straps hold a small tripod or your jacket on the bottom of the pack

Orion AW BeltPack Size: 13.5W x 6.5D x 8.75H in. (34.5 x 16.5 x 22 cm)
Weight: 2lb, 14 oz. 1304 g

Orion AW DayPack Size: 13.5 x 7D x 11.5H in. (34.5 x 18 x 29 cm)
Weight: 14 oz. 285 g
Colors: Black, Forest Green Materials: 600D TXP and 600D TXP ripstop

ADJUSTING THE BELTPACK

1. Remove the daypack and shoulder strap from the belt pack.
2. Tighten the belt so that the weight rests on your hips. Tighten the BatWing straps to stabilize the load and pull it towards the lower back. See Figure 1.
3. Use the shoulder strap and the waistbelt for better weight distribution and security. See Figure 2. Most of the load should be carried on your hips with the shoulder strap providing some support. To access gear, loosen the waistbelt enough to rotate the pack around to the front and let the shoulder strap drop forward.

ADJUSTING THE BACKPACK

4. Remove the backpack from inside the belt pack. Remove the shoulder strap from the belt pack and unhook the gray straps from the metal D-ring. Put the daypack on your back and adjust the triglides on the harness so the pack fits comfortably.
5. Take the daypack off your back and place it on top of the belt pack so the logos face the same way. Take the gray straps tucked in the bottom of the daypack, put the male quick-release buckles on each side of the daypack through the D-rings. See Figure 3.
6. Pull the male quick-release buckles up to the bottom of the shoulder harness straps and connect them to the female quick release buckle. See Figure 4.
7. Pick up the pack and put it on your back. Fasten the waistbelt and tighten it so that the pack rests on your hips. The belt pack should remain on your hips, even after the shoulder harness is adjusted. Tighten the shoulder harness. Most of the weight should still be carried on your hips with the harness providing some support. You can adjust the weight distribution during the course of wearing the pack. See Figure 5.

8. Tighten the BatWing straps. These straps stabilize the load and pull it towards your lower back. See Figure 1.

9. Tighten the sternum strap. You can change the vertical position so that the strap fits comfortably. This strap reduces shoulder fatigue and increases mobility by pulling the shoulder straps inward. See Figure 6.

TO ACCESS EQUIPMENT WHEN USING DAYPACK

10. Release quick-release buckles on gray straps from the shoulder harness of the daypack. See Figure 7. Loosen the strap through the buckles. Let the strap slide through the D-rings. See Figure 8.
11. Loosen the waistbelt slightly and rotate the belt pack to the front of your body to access equipment. See Figure 9.

USING THE ALL WEATHER COVER™ (patented)

12. Remove the cover from the storage compartment located under the front pocket of the belt pack. See Figure 10.
13. Make sure that the wide elastic band is on the outside of the All Weather Cover. Pull the top of the cover over the top of the belt pack and secure it around the edges as in Figure 11
14. Pull the part of the cover joined by the wide elastic band all the way to the back and around the belt pack. Push the D-rings through the openings in the cover so that the backpack or shoulder strap can be attached.

USING THE TRIPOD STRAPS

15. Pull out the black tripod straps tucked under the belt pack bottom. See Figure 12.
16. Put your tripod through the loops and tighten the tripod straps. See Figure 13.




Figure 1




Figure 2




Figure 3



Figure 4



Figure 5




Figure 6



Figure 7



Figure 8



Figure 9



Figure 10



Figure 11